

**LONCIN** 隆鑫

**General Power Products**

## **Gasoline Engine**

# **LC154**

## **Owner's Manual**



# CONTENTS

---

## CONTENTS

|  |    |
|--|----|
| 1. ENGINE SAFETY.....                  | 2  |
| 2. COMPONENTS & CONTROL LOCATIONS..... | 3  |
| 3. CONTROLS.....                       | 4  |
| Fuel cock                              |    |
| Engine switch                          |    |
| Choke lever                            |    |
| Recoil starter                         |    |
| Governor lever                         |    |
| Oil alert                              |    |
| 4. CHECK BEFORE OPERATION .....        | 6  |
| Check                                  |    |
| Check oil                              |    |
| Check fuel                             |    |
| Check air cleaner                      |    |
| 5. STARTING ENGINE.....                | 8  |
| 6. STOP ENGINE .....                   | 10 |
| 7. MAINTENANCE .....                   | 11 |
| Schedule                               |    |
| Renewing engine oil                    |    |
| Maintaining air cleaner                |    |
| Washing sediment cup                   |    |
| Spark plug                             |    |
| Adjusting idle speed                   |    |
| 8. STORAGE .....                       | 16 |
| 9. TROUBLESHOOTING .....               | 17 |
| 10. ENGINE PARAMETER.....              | 20 |
| 11. WIRING DIAGRAMS.....               | 21 |

## ENGINE SAFETY

---

### 1. ENGINE SAFETY

#### IMPORTANT SAFETY INFORMATION

Most accidents with engines can be prevented if you follow all instructions in this manual and on the engine. Some of the most common hazards are discussed below, along with the best way to protect yourself and others.

#### Owner Responsibilities

- The engines are designed to give safe and dependable service if operated according to instructions. Read and understand this owner's manual before operating the engine. Failure to do so could result in personal injury or equipment damage.
- Know how to stop the engine quickly, and understand the operation of all controls. Never permit anyone to operate the engine without proper instructions.
- Do not allow children to operate the engine. Keep children and pets far away from the area of operation.

#### Refuel With Care

Gasoline is extremely flammable, and gasoline vapor can explode. Refuel outdoors, in a well-ventilated area, with the engine stopped. Never smoke near gasoline, and keep other flames and sparks away. Always store gasoline in an approved container. If any fuel is spilled, make sure the area is dry before starting the engine.

#### Hot Exhaust



- The muffler becomes very hot during operation and remains hot for a while after stopping the engine. Be careful not to touch the muffler while it is hot. Let the engine cool before storing it indoors.
- To prevent fire hazards and to provide adequate ventilation for stationary equipment applications, keep the engine at least 3 feet (1 meter) away from building walls and other equipment during operation. Do not place flammable objects close to the engine.

#### Carbon Monoxide Hazard

Exhaust gas contains poisonous carbon monoxide. Avoid inhalation of exhaust gas. Never run the engine in a closed garage or confined area.

## COMPONENTS & CONTROL LOCATIONS

### 2. COMPONENTS & CONTROL LOCATIONS




# CONTROLS

---

## 3. CONTROLS


### 1) Engine Switch

The engine switch enables and disables the ignition system.  
The engine switch must be in the ON position for the engine to run.  
Turning the engine switch to the OFF position stops the engine.



### 2) Choke Lever

The choke lever opens and closes the choke valve in the carburetor.  
Set lever "CLOSE" for starting a cold engine.  
After starting, set the choke lever to "OPEN" position



### 3) Recoil Starter Grip


Pulling the starter grip operates the recoil starter to crank the engine.

**CAUTION**

Don't let the lever suddenly rebound, lightly put the lever back.


## CONTROLS

---



### 4) Governor lever

Adjust the throttle lever position to get required speed.



For proper engine speed, refer to indication provided by equipment.

### 5) Oil protecting system

The oil protecting system is used for preventing from oil insufficiency in the crankcase, when oil lowering lower limit, the oil protecting system will automatically make the engine stopping.(engine still keep the "OPEN" position.)

**CAUTION**

If automatically stopping and not starting, first, check the oil lever, then, check other trouble.

## CHECK BEFORE OPERATION

---

### 4. CHECK BEFORE OPERATION

#### 1) Check


- Look around and underneath the engine for signs of oil or gasoline leaks.
- Look for signs of damage.
- Check that all shields and covers are in place, and all nuts, bolts, and screws are tightened.

#### 2) Check oil

**CAUTION**

When stopping the engine at horizontal place, check the oil

- 1) Take the oil dipstick and clean
- 2) Insert the oil dipstick in and check the oil level without screwing down.
- 3) If the oil is too low, add the recommended oil in.
- 4) After finishing, reassemble and screw the oil dipstick down.



The Oil Alert system (applicable engine types) will automatically stop the engine before the oil level falls below safe limits. However, to avoid the inconvenience of an unexpected shutdown, always check the engine oil level before startup.

#### 3) Check fuel


First stop the engine, open the fuel cover, and check oil level., if the oil level is too low, add the fuel to full, after finishing, screw the fuel cover down.  
Don't add the fuel over the shoulder of the carburetor when fueling (maximum oil level).

Fuel tank volume:

154F: 1.6 L

## CHECK BEFORE OPERATION

---




Recommended octane rating over 90 unleaded gasoline

For unleaded gasoline, can make carbon deposit muck less and enhance exhaust system service life

Don't use used and contaminated or gasoline with oil , Avoid the dirt and water entering into fuel tank.

### 4) Check air cleaner

Remove the air cleaner housing and check the element, if the element dirt, clean it, if damaged, renew.






## Starting engine


---

### 5. Starting engine


- 1) To start a cold engine, move the choke lever to the "CLOSE" position.  
To start a warm engine, turn the choke lever to the "OPEN" position.



- 2) Move the throttle lever away from the "LOW" position, about 1/3 of the way toward the "HIGH" position.



- 3) Turn the engine switch to the "ON" position.




## Starting engine

---


4) Pull the starter grip lightly until you feel resistance, then pull briskly.

**CAUTION**

Don't let starting lever suddenly rebound, and lightly put the lever back.



5) If the choke lever has been moved to the "CLOSE" position to start the engine, gradually move it to the "OPEN" position as the engine warms up.




## STOPPING THE ENGINE

---


### 6. STOPPING THE ENGINE

To stop the engine in an emergency, simply turn the engine switch to the “OFF” position. Under normal conditions, use the following procedure.

- 1). Move the throttle lever to the “LOW” position.



- 2) Turn the engine switch to the “OFF” position.



## MAINTENANCE

### 7. MAINTENANCE

#### SCHEDULE

| REGULAR SERVICE PERIOD    |              | Each use                                 | First month or 20 Hrs. | Every 3 months or 50 Hrs. | Every 6 months or 100 Hrs. | Every year or 300 Hrs. |
|---------------------------|--------------|--|------------------------|---------------------------|----------------------------|------------------------|
| Engine oil                | Check level  | ○  |                        |                           |                            |                        |
|                           | Change       |  | ○                      |                           | ○                          |                        |
| Air cleaner               | Check        | ○  |                        |                           |                            |                        |
|                           | Clean        |  |                        | ○(1)                      |                            |                        |
|                           | Replace      |  |                        |                           |                            |                        |
| Sediment Cup              | Clean        |  |                        |                           | ○                          |                        |
| Spark plug                | Clean        |  |                        |                           | ○                          | Replac<br>e            |
| Valve clearance           | Check-Adjust |  |                        |                           |                            | ○(2)                   |
| Cover comp head           | Clean        | After every 300 Hrs. (2)                 |                        |                           |                            |                        |
| Fuel tank and fuel filter | Clean        | Every 2 years (Replace if necessary) (2) |                        |                           |                            |                        |
| Fuel line                 | Check        | Every 2 years (Replace if necessary) (2) |                        |                           |                            |                        |

(1) Service more frequently when used in dusty areas.

(2) These items should be serviced by your servicing dealer unless you have the proper tools and are mechanically proficient.

#### RENEWING ENGINE OIL

Drain the used oil while the engine is warm. Warm oil drains quickly and completely.


1. Place a suitable container below the engine to catch the used oil, and then remove the pad and dipstick and the drain plug.
2. Allow the used oil to drain completely, and then reinstall the drain plug and pad, and tighten it securely.

Please dispose of used motor oil in a manner that is compatible with the environment. We suggest you take used oil in a sealed container to your local recycling center or service station for reclamation. Do not throw it in the trash; pour it on the ground; or down a drain.

3. With the engine in a level position, fill to upper limit with the recommended oil.

## MAINTENANCE

---



#### 4) Assembling oil dipstick and screwing down

Recommended oil:

Use 4-stroke automotive detergent oil.

We recommend that you use API SERVICE Category SE or SF oil or equivalent to SG grade SAE 10W-30.

You can use this brand oil if your area temperature list within some brand oil temperature range

### MAINTAINING AIR CLEANER

A dirty air filter will restrict air flow to the carburetor, reducing engine performance.

If you operate the engine in very dusty areas, clean the air filter more often than specified in the MAINTENANCE SCHEDULE.

**NOTICE**


Operating the engine without element or with a damaged element will allow dirt to enter the engine, causing rapid engine wear.

## MAINTENANCE

---

### Air cleaner

- 1) Screw off air cleaner bolt and remove the cover.



- 2) Remove foam element

Check element and renew if damaged.

#### Wash foam element:

Wash the cover and filter in warm, soapy water, rinse, and allow drying thoroughly. Or clean in nonflammable solvent and allow drying. Dip in clean engine oil, and then squeeze out all excess oil.

1. Empty the used oil from the air cleaner case, wash out any accumulated dirt with nonflammable solvent, and dry the case.
- 3) Clean the air cleaner I, cover and rubber gasket, preventing dust entering into carburetor.
- 4) Reassemble the foam element, paying attention to rubber gasket underneath the element.
- 5) Reassemble the air cleaner, and tighten the wing nut securely.


### WASHING SEDIMENT CUP

(First check fuel tank for fuel, if having, drain the fuel in the fuel tank completely.)

1. Remove the fuel sediment cup and O-ring.
2. Wash the sediment cup and O-ring in nonflammable solvent, and dry them thoroughly.

## MAINTENANCE

3. Place the O-ring in the fuel valve, and install the sediment cup. Tighten the sediment cup securely.
4. Move the fuel valve to the ON position, and check for leaks. Replace the O-ring if there is any leakage.




### SPARK PLUG

Recommended spark plugs: E7RTC or other equivalents.

#### NOTICE

An incorrect spark plug can cause engine damage.

1. Disconnect the spark plug cap, and remove any dirt from around the spark plug area.
2. Remove the spark plug with a spark plug wrench.



3. Inspect the spark plug. Replace it if the electrodes are worn, or if the insulator is cracked or chipped. The gap should be 0.028 -0.031 in (0.70 - 0.80 mm). Correct the gap, if

## MAINTENANCE

---

necessary,

4. Install the spark plug carefully, by hand, to avoid cross-threading.
5. After the spark plug seats, tighten with a spark plug wrench to compress the water.

If reinstalling the used spark plug , tighten 1/8 - 1/4 turn after the spark plug seats.


If installing a new spark plug, tighten 1/2 turn after the spark plug seats.

6. Assemble spark plug.

### ADJUSTING IDLE SPEED

1. Start the engine outdoors, and allow it to warm up to operating temperature.
2. Move the throttle lever to its slowest position.
3. Turn the idle speed screw to obtain the standard idle speed.

Standard idle speed:  $1,800 \pm 150$  rpm





## STORING YOUR ENGINE

---


### 8. STORING YOUR ENGINE

If the engine has been running, allow it to cool for at least half an hour before cleaning. Clean all exterior surfaces, repair any damaged paint, and coat other areas that may rust with a light film of oil.

**CAUTION**

Water with big pressure can enter into air cleaner and muffler and even into cylinder along with air path, resulting in causing rust and water spatter on the hot engine to damage engine, so don't wash engine until the engine is cooled.

- 1) Place a container underneath the carburetor, and use funnel for oil not spattering, close fuel cock.
- 2) Remove the drain plug and sediment cup, then, open the fuel cock.



- 3) Immediately reassemble sediment cup and drain bolt after fuel completely draining. And screw down.
- 4) Change the engine oil.
- 5) Remove the spark plugs.
- 6) Pour a tablespoon (5-10 cc) of clean engine oil into the cylinder.
- 7) Pull the starter rope several times to distribute the oil in the cylinder.
- 8) Reinstall the spark plugs.
- 9) Pull the starter rope slowly until resistance is felt. This will close the valves so moisture cannot enter the engine cylinder. Return the starter rope gently.
- 10) Put the out case on the engine and place in the ventilated and dry area.

## Troubleshooting

### 9. Troubleshooting

#### 1) Starting difficult

| Phenomenon                         | Possible Cause     |                      |                                | Correction                             |                                 |
|------------------------------------|--------------------|----------------------|--------------------------------|--|---------------------------------|
| Cylinder pressure normal           | Spark plug normal  | Fuel system abnormal | Oil path unpassing             | No fuel, oil cock closed               | Add fuel, open the oil cock     |
|                                    |                    |                      |                                | Air hole clogged                       | Clean clogged                   |
|                                    |                    |                      |                                | Oil cock clogged                       | wash                            |
|                                    |                    |                      |                                | Main jet adjusted not well, or clogged | Readjust, wash and blow         |
|                                    |                    |                      | Needle valve or float blocked. | Repair or renew                        |                                 |
|                                    |                    |                      | Oil path passing               | Fuel too dirt or deteriorated          | Renew fuel or clear carburetor  |
|                                    |                    |                      |                                | Water in the fuel                      | Renew fuel and clean carburetor |
|                                    |                    |                      |                                | Too much fuel in the cylinder          | Drain fuel and clean spark plug |
|                                    | Wrong fuel         | Change fuel          |                                |  |                                 |
|                                    | Fuel system normal | Spark normal         | Spark plug poor                | Carbon deposit and dirt electrode      | Clean carbon deposit and dirt   |
|                                    |                    |                      |                                | Damaged insulator                      | Renew spark plug                |
|                                    |                    |                      |                                | Electrode burn through.                | Renew spark plug                |
|                                    |                    |                      |                                | Wrong gap                              | Adjust gap                      |
|                                    |                    | Spark normal         | No spark                       | High tension coil damaged              | Renew high tension coil         |
| Igniter coil damaged               |                    |                      |                                | Renew high tension coil                |                                 |
| Magnetic field strength not enough |                    |                      |                                | Charge magnetic or renew               |                                 |
|                                    |                    |                      |                                |  |                                 |
| Cylinder pressure abnormal         | Fuel system normal | Igniter normal       | Spark plug normal              | Piston ring worn or broken.            | Renew                           |
|                                    |                    |                      |                                | Ring cementation                       | Clean carbon deposit            |
|                                    |                    |                      |                                | No washer or not tightening            | Add washer or tighten           |
|                                    |                    |                      |                                | Leaking from joint                     | Renew gasket                    |
|                                    |                    |                      |                                | valve sealing poor                     | Lap or renew                    |

#### 2) ENGINE LACKS POWER

## Troubleshooting

---

| Phenomenon   | Possible Cause   |  | Correction                   |
|--|------------------|--|------------------------------|
| When increasing throttle speed up or slowly or speed down or stop the engine | Ignition system  | Ignition time not right                    | Replace ignition coil        |
|  | Fuel system      | Fuel path with air                         | Exhaust air                  |
|  |                  | Wrong adjustment of main jet               | Readjustment                 |
|  |                  | Needle valve and main jet clogged          | Clean and blow               |
|  |                  | Oil cock clogged                           | Clean or replace             |
|  |                  | Carbon deposit in the combustion chamber   | Clean carbon deposit         |
|  | Intake system    | Air cleaner clogged                        | Clean or replace             |
|  |                  | Intake system clogged                      | Repair or replace            |
|  | Compression poor | Piston, cylinder piston ring worn          | replace                      |
|  |                  | Leakage between cylinder and cylinder head | Replace cylinder head gasket |
|  |                  | Valve gap not right                        | Readjustment                 |
| Valve sealing leakage  |                  | Grinding or replacement                    |                              |

### 3) SUDDENLY STOP THE ENGINE

| Phenomenon               | Possible Cause  |   | Correction                      |
|--------------------------|-----------------|---|---------------------------------|
| Suddenly stop in running | Fuel system     | No fuel   | Refuel and pass through         |
|                          |                 | Carburetor clogged                                  | Check fuel path                 |
|                          |                 | Carburetor float leaking fuel                       | Repair float                    |
|                          |                 | Needle valve blocked                                | Repair                          |
|                          | Ignition system | Spark plugs breakdown, carbon deposit short circuit | Replace spark plug              |
|                          |                 | Spark plug electrode fallen off                     | Replace spark plug              |
|                          |                 | High tension line fallen off                        | Repair and replace              |
|                          |                 | Ignition coil breakdown                             | Replace                         |
|                          | Others          | Serious scuffing and valve fallen off               | Repair or replace damaged parts |

### 4) ENGINE OVERHEATING

## Troubleshooting

| Phenomenon                  | Possible Cause                 | Correction  |
|-----------------------------|--------------------------------|---|
| Gasoline engine overheating | Ignition time not right        | Replace ignition coil                                 |
|                             | Gasoline not enough            | Refill gasoline                                       |
|                             | Exhaust pipe clogged           | Clean exhaust pipe                                    |
|                             | Guided air shield clogged      | Repair  |
|                             | Air path clogged               | Clean air cooling fin                                 |
|                             | Cooling fan damaged            | Reinstall   |
|                             | Gas leaking from ring to down  | Replace damaged parts                                 |
|                             | Gasoline engine speed too high | Check and governor speed system or replace speed gear |
|                             | Crankshaft bearings burned     | Replace or repair                                     |

### 5) Abnormal sound

| Phenomenon                   | Possible Cause                               | Correction                           |
|------------------------------|--|--------------------------------------|
| Knocking sound               | Piston and piston ring worn                  | Replace damaged parts                |
|                              | Connecting rod, piston pin and pin hole worn | Replace damaged parts                |
|                              | Crankshaft bearings worn                     | Replaces or repair                   |
|                              | Piston rings broken                          | Replace piston rings                 |
| Deflagration and metal sound | Combustion charmer carbon deposit too much   | Clean carbon deposit                 |
|                              | Spark plug electrode gap too narrow          | Adjust electrode gap                 |
|                              | Engine flooded with fuel                     | Check carburetor                     |
|                              | Wrong fuel                                   | Replace fuel                         |
|                              | Gasoline engine overheating                  | Refer to overheated trouble column   |
| Other abnormal sounds        | Valve gap adjustment wrong                   | Readjust valve gap                   |
|                              | Flywheel connection with crankshaft loosen   | Replace connecting key and reinstall |

## ENGINE PARAMETER

---

### 10. ENGINE PARAMETER

| Model                              | 154F  |     |
|------------------------------------|---|-----|
| Type                               | Single cylinder 4-Stroke Forced air cooling OHV   |     |
| Rated power<br>(kW/3600rpm)        | 1.6Kw/3600rpm                                     |     |
| Max power<br>(Kw/4000rpm)          | 2.0Kw/4000rpm                                     |     |
| Max torque N·m/rpm                 | 4.5N.m/3000rpm                                    |     |
| Fuel consumption ratio<br>(g/kW·h) | ≤450  |     |
| Idle speed<br>(rpm)                | 1800±150  |     |
| Speed fluctuating ratio            | ≤10%  |     |
| Noise ≤ dB(A)                      | 70  |     |
| Bore×Stroke mm                     | 54×38   |     |
| Displacement cc                    | 87  |     |
| Compression ratio                  | 8:1   |     |
| Lubricating mode                   | Splash  |     |
| Starting mode                      | Recoil start                                      |     |
| Rotation                           | Anti-clockwise(from P.T.O.Side)                   |     |
| Valve clearance mm                 | Intake valve 0.10-0.15<br>Exhaust valve 0.15-0.20 |     |
| Spark plug gap mm                  | 0.7~0.8   |     |
| Ignition mode                      | Transistorized magneto ignition                   |     |
| Air cleaner                        | Single element                                    |     |
| Dimension<br>mm                    | Length  | 310 |
|                                    | Width   | 225 |
|                                    | Height  | 305 |
| Net weight kg                      | 10.5  |     |

## WIRING DIAGRAMS


---

### 11. WIRING DIAGRAMS

Non-electric starting engine with oil protection system

|       | IG | E | ST | BAT |
|-------|----|---|----|-----|
| OFF   | ○  | ○ |    |     |
| ON    |    |   |    |     |
| START |    |   | ○  | ○   |

|    |        |
|----|--------|
| Bl | black  |
| Y  | yellow |
| G  | green  |





**Loncin motor co., Ltd.**

Add: No. 99 Hualong Road, Jiulongpo District, Chongqing, China

Tel: 86 23 8980 5678 / 86 23 8980 8505

Fax: 86 23 8906 7566

Email: [marketing@loncinengine.com](mailto:marketing@loncinengine.com)

Website: [www.loncinengine.com](http://www.loncinengine.com)

**PRINTED IN CHINA**