

Maintenance of the Engine's Appearance

- 1) The appearance of engine should be regularly checked and the dirt shall be regularly cleansed.
- 2) Take out the filter net (figure 1, 2) and put it in clean kerosene or diesel to cleanse.
- 3) Take off the filter cover of the engine oil (figure 3), put the oil filter of the engine oil in clean kerosene or diesel to cleanse.







figure 1



filter net of the engine oil



filter cover

figure 3

