

日常保养和维护/Routine maintenance

保养的重要性/The importance of maintenance

良好的保养对于安全、经济、正常运行非常重要，有助于延长您的发动机的寿命，同样对减少污染也有帮助。

Good maintenance is very important for safe, economic, normal operation, and also helpful to extend your engine life, and reduce pollution.

| 定期维护时间表 Regular maintenance schedule | 每次使用 Each use | 第一个月或20小时 First month Or 20 hours | 每3个月或每50小时 Every 3 months Or every 50 hours | 每6个月或每100小时 Every 6 months Or every 100 hours | 每年或300小时 Per year Or every 300 hours |
|---|--|--------------------------------------|--|--|---|
|  | 检查机油油位/Check oil level | | | | |
| | ● | | | | |
|  | 机油更换/Oil change | | | | |
| | | ● | ● | | |
|  | 空滤器清洁/Air filter cleaning | | | | |
| | | | ●① | | |
|  | 空滤器更换/Air filter replacement | | | | |
| | | | | | ●* |
|  | 火花塞检查调整/Check and adjust spark plug | | | | |
| | | | | ● | |
|  | 火花塞更换/Spark plug replacement | | | | |
| | | | | | ● |
|  | 火花消除器清洁 (可选件)/Spark arrestor cleaning (optional part) | | | | |
| | | | | ● | |
|  | 怠速检查调整/Check and adjust idle speed | | | | |
| | | | | | ●② |
|  | 气门间隙检查调整/Check and adjust valve clearance | | | | |
| | | | | | ●② |
|  | 燃油箱及燃油过滤器清洁/Fuel tank and fuel filters clean | | | | |
| | | | | ●② | |
|  | 燃油管清洁/Clean Fuel line | | | | |
| | 每2年后 (如有必要进行更换) Every 2 years (and replaced if necessary) | | | | |

● 保养事项/Maintenance matters

* 只更换泡沫及纸质滤芯部分/Only the replacement of foam and paper filter some

① 在灰尘大的地方使用应缩短维护周期/Used in dusty areas should be shortened maintenance cycle

② 除非用户有专业维修工具和维修技能，否则这些项目应由隆鑫特约经销商协助维护。

Unless the user has maintenance tools and professional skills, otherwise these items should be maintained by Loncin's authorized dealer.